
ANALOG KEYS/ANALOG FOUR SOUND PACK

Congratulations! You're just minutes away from accessing a new range of sounds. Get creative. Experiment. Make music like there's no tomorrow. These sounds are 100% royalty free and may be used, reshaped and combined in any way you see fit.

The following step-by-step instruction will help you install the Sound Pack sounds that you just downloaded.

Basic knowledge of Analog Keys/Four functionality is required. If you should need to brush up on how to interact with your instrument, please consult the Analog Keys or the Analog Four **User Manual**, available for download free of charge from the Elektron website. Please note that all words written in **bold** typeface above and below (except the **[KEY INDICATORS]** and the **ENCODER INDICATORS**) are clickable and will lead you to the corresponding web resource.

TRANSFERRING THE SOUNDS

1. Connect Analog Keys/Four to a computer using the USB A to B cable. Please note that the Analog Keys/Four will not appear as an icon on your computer desktop.
2. On the Analog Keys/Four, make sure data is received via USB. Open the GLOBAL menu. Select the fifth item in the list, MIDI CONFIG, and press **[YES/SAVE]**. Select the second item in the list, MIDI PORT CONFIG, and press **[YES/SAVE]**. Select the fourth item in the list, INPUT FROM, and select USB using the **[ARROW]** keys.
3. Prepare your Analog Keys/Four to receive the sounds in a suitable Sound Bank slot. Open the GLOBAL menu. Select the eighth item in the list, SYSEX DUMP and press **[YES/SAVE]**. Select SYSEX RECEIVE and press **[YES/SAVE]**. Using the **[ARROW]** keys, highlight +DRIVE SOUNDS on the left hand menu and press **[YES/SAVE]**. The highlight bar will now appear on the right hand menu. This is where you select the Sound Bank that will receive the new sounds. Select Sound Bank position using the **[ARROW]** keys. Sound Bank A and B normally contains preset sounds, so in this example we will select Sound Bank C.
4. Highlight Bank C and press **[YES/SAVE]**. The words "WRITING DATA..." will be shown flashing on the chosen Sound Bank position, indicating that it is ready to receive the .syx file from the computer. Note that if the Sound Bank already contains sounds that aren't locked (consult the **User Manual** on how to do this), they will be overwritten with the new sounds. Make sure you select an unpopulated Sound Bank, or a Sound Bank that contains sounds that you can do without. Press **[NO/RELOAD]** if you wish to abort the Analog Keys/Four listening for .syx data and choose another Sound Bank position.
5. On the computer, open the **c6 utility software** (make sure you have the latest version, available on the Elektron website). On the c6 Configuration menu, select Elektron Analog Keys/Four for both MIDI In and MIDI Out. Close the Configuration window by clicking the OK button.
6. Drag the .syx file containing the Sound Pack sounds to the c6 main window. Make sure you highlight the file, once it is visible in the c6 main window, by pointing and clicking on it. Press the SEND button. A progress bar will appear at the bottom of the c6 window. On the Analog Keys/Four LCD screen you will see "WRITING DATA..." for the duration of the transfer. Transferring the sounds will take a few seconds.

ACCESSING THE SOUNDS

1. Select a synth track by pressing any of the **[TRACK]** keys. On the Analog Keys, nudge the **SOUND SELECTION** wheel (on the Analog Four, double-tap the **[TRACK]** key) to open the SOUND BROWSER. Make sure you view the +DRIVE sounds (check that each sound is indexed with both Sound Bank and position, "C:001" above the name of the sound). If, on the other hand, the Sound Pool is in view (sounds are indexed with position only, "001"), press the left **[ARROW]** key in order to bring up the left hand menu and select the first item in the list, VIEW +DRIVE, and press **[YES/SAVE]**.
2. Inside the SOUND BROWSER, first press the **[TRIG]** key that corresponds to the Sound Bank where you chose to plant the new sounds (Trig 1 = Sound Bank A, Trig 2 = Sound Bank B, and so on). If you're following these instructions to a fault, remember from the above section that we chose Sound Bank C. Consequently, press **[TRIG]** key 3.
3. Use the **[ARROW]** keys to browse through the new sounds. Preview a highlighted sound by pressing a key on the **[KEYBOARD]**. Press **[YES/SAVE]** to select the sound. Play that music!

The Sounds of the Analog Keys/Four sound packs remain the property of its manufacturer (Collectively, "Licensor") and are licensed to you as the original end-user ("Licensee"), for use subject to the provisions below. All rights not expressly granted herein are reserved exclusively by Licensor.

The Sounds in a category of 'Sound pack':

1. The Licensee may use the Sounds in combination with other sounds in music productions (which include soundtracks of such as films, video productions, radio/TV programs or commercials, computer games and multimedia presentations, library music), public performances, and other reasonable musical purposes within musical compositions.
2. The Licensee may modify the Sounds and may use the Sounds for commercial purposes as part of a musical composition with other sounds.
3. The Licensee MAY NOT use the Sounds in isolation as sound effects (i.e. a sequence of musical events) or within any competitive products that are sold or relicensed to multiple third parties. In these scenarios the Licensee must arrange an extension with Elektron Music Machines.
4. A right to use the sounds is granted only to the Licensee and is NOT transferable. This license expressly forbids resale, relicensing or other distribution of the Sounds, either as they exist or any modification thereof. You cannot sell, loan, rent, lease, assign, upload to or download from any server, or transfer all or any of the enclosed sounds to another user, or for use in any competitive product.
5. Licensor will not be responsible if the sounds does not fit the particular purpose of the Licensee.